



43 Industrial Avenue, Hoppers Crossing, Victoria 3029

T (03) 9369 5833, F (03) 9369 5884, [info@tstcarpets.com.au](mailto:info@tstcarpets.com.au), [www.tstcarpets.com.au](http://www.tstcarpets.com.au)

Automotive carpet products, Domestic and commercial carpet, Synthetic grass, Promotional Mats,  
Indoor/Outdoor entrance mats & healthcare mats.



## Moulded Car Carpet Fitting Instructions

1. Remove door sill plates, kick panels, front and rear seat bases, consoles, seat belt bolts and any other items fixed to the existing carpet.
2. Remove old carpet and retain for step 5.
3. Remove old underfelt making a note of its position in the vehicle.
4. Clean the area in preparation for fitting the new carpet.
5. Place the old carpet over the new carpet to form a template and mark holes and cut outs with chalk (do not cut at this point).
6. Install new underlay or replace original underlay in the same position the underlay was removed from the vehicle.
7. Starting from the rear, place your new moulded carpet in the vehicle centering it on the tunnel and working towards the sides.
8. Repeat step 7 for the front carpet.
9. Push the front carpet forwards to tighten the carpet over the tunnel/hump, the top of the carpet may need to be trimmed to fit. Ensure you match the contours of the carpet with the floor to confirm the correct fit. You may need to cut the holes marked in step 5. Start with a small hole, then enlarge gradually if required.
10. Depending on your vehicle model, trim sides of carpet (excess is given to allow for adjustment in the fitting process).
11. Replace all trims and fixtures removed in step 1.

**Congratulations! Enjoy your new carpet!**

\*Please note – These instructions are generic, to be used as a guide only. For assistance with fitting please consult with your local motor trimmer.